APEM

Switches &

Pilot Lights

Emergency

Enabling Switches

Stop Switches

Safety Products

Explosion Proof

Terminal Blocks

Relays & Sockets Circuit Protectors Power Supplies LED Illumination Controllers Operator Interfaces Sensors AUTO-ID

## FB Series Control Stations

## IP65 lightweight control stations. IDEC HW and XW series switches and pilot lights installed.

- ø22 mm switches/pilot lights can be installed.
- Blank front enclosures, without mounting holes, are also available.
- Blank front enclosures can also be used as junction boxes to mount terminal blocks.
- Yellow cover enclosures for emergency stop switches are also available.
- · Front panel mounting, rear panel mounting, hook mounting, and frame mounting options are available.

<sub>c</sub>(UL)<sub>us</sub> CE LISTED

- Contact cover box (Part no.: FB1WBR) is not UL or c-UL listed.
- Enclosures without mounting hole is not UL or c-UL listed.
- (Enclosures less than 1,639 cm<sup>3</sup> is not approved by UL50, 2:8.)
- · See website for details on approvals and standards.

Enclos	ures			Package Quantity:
Size   Mounting			Cover Color (*1)	Part No.
	0	Without mounting hole	Light beige	FB1T-000Z
76mm	6mm 1 ø22mm		Yellow	FB1W-111Y
	1	ø22mm	Light beige	FB1W-111Z
	0	Without mounting hole	Light beige	FB2T-000Z
140mm	2	ø22mm, mounting centers 50mm	Light beige	FB2W-211Z
	3	ø22mm, mounting centers 30mm	Light beige	FB2W-312Z
	0	Without mounting hole	Light beige	FB3T-000Z
200mm	3	ø22mm, mounting centers 50mm	Light beige	FB3W-311Z
200mm	4	ø22mm, mounting centers 36mm	Light beige	FB3W-413Z
	5	ø22mm, mounting centers 30mm	Light beige	FB3W-512Z

\*1) Light beige (Munsell 5Y7/1 or equivalent), Yellow (Munsell 2.5Y8/10 or equivalent), Enclosure base color: Black (Munsell N1.5 or equivalent)



Contact Cover Box Package Quantity:							
Size	No. of Mounting Holes	Mounting Hole Description	Cover Color	Part No.			
76mm	1	ø22 mm hole in the base	Light beige	FB1WR-111Z			
• For opera	• For operating instructions, see C-019.						

#### Accessories

Description	Part No.	Ordering No.	Package Quantity
Mounting Bracket	FB9Z-PK1	FB9Z-PK1	1
DIN Rail Adapter	FB9Z-PK3	FB9Z-PK3PN02	2
Mounting Hole Plug	LW9Z-BP1	LW9Z-BP1	1


· Connectors and nuts are supplied by users.

## Specifications (\*2)

Applicable Standards	IEC/EN60529 UL508 UL50 CSA C22.2 No. 14 CSA C22.2 No. 94
Standard Operating Conditions	Ambient temperature:       -25 to +60°C (no freezing)         Relative humidity:       45 to 85%RH (no condensation)         Storage temperature:       -40 to +80°C (no freezing)         Degree of pollution:       3
Degree of Protection	IP65 (when IP65 switches/pilot lights are installed) NEMA Type 4X Indoor Use Only (when Type 4X switches/pilot lights are installed)
Electric Shock Protection	Class II (when class II switches/pilot lights are installed)
Material	Box cover / box base: polycarbonate (*5) Box cover mounting screw: stainless
Applicable Switches/ Pilot Lights	IDEC's HW/TW/XW series and accessories (*3) (*4)
Weight (approx.)	76 mm: 125g (FB1W-111Y) 140 mm: 184g (FB2W-211Z) 200 mm: 243g (FB3W-311Z)

\*2) The above specifications are for enclosures. For switches/pilot lights, refer to the specifications of each unit.


- \*3) Choose switches/pilot lights and accessories which match the mounting hole centers, effective depth behind the cover, and the thickness of the cover where switches/pilot lights are installed (3 mm). Note that enclosures with 30 mm or 36 mm mounting hole centers may limit the knob orientation of selector switches, because the contact blocks can be mounted in one direction only on these mounting centers.
- \*4) An XW series emergency stop switch of screw terminal model can be installed on an enclosure with one mounting hole or mounting holes of 50 mm mounting centers, by connecting one clamping terminal to one terminal pole. \*5) Flame-resistant (UL94V-0).



## For more information, visit http://eu.idec.com


All dimensions in mm.

## **Dimensions**




#### **FB Series Control Stations**


With ø22 mm XW Series EMO Switches





#### **FB Series Control Stations**

With ø22 mm XW Series EMO Switches + SEMI Switch Guard (HW9Z-KG4)









APEM Switches & Pilot Lights Control Boxe Emergency Stop Switches Enabling Switches Safety Products Explosion Proof Terminal Blocks Relays & Sockets

106 166 Circuit Protectors

Power Supplies


**Control Boxes** 

LED Illumination

Controllers

Operator Interfaces


Sensors AUTO-ID




ø14 Knockout



## **Internal Dimensions**



Choose an enclosure in consideration of switch's depth behind the panel and the mounting centers of the adjacent switches.



**FB Series Control Stations** 

SEMI Switch Guard (HW9Z-KG3)

076

5

59.5 °₽́

## С With ø22 mm XW Series EMO Switches + 4-M4 tapping holes fo rear mounting (Depth: 10mm 2-Front Mounting Holes

APEM

## Switch/Pilot Light Mounting Hole Centers

Model	76mm	140	mm	200mm				
M	7011111	2 mounting holes	mounting holes 3 mounting holes		4 mounting holes	5 mounting holes		
Shane						20/30/30/30		


## Switches & Pilot Lights Emergency Stop Switches Enabling Switche Safety Products Explosion Proof Terminal Blocks Relays & Sockets Circuit Protectors Power Supplies LED Illumination Controllers

Applicable Accessories

o Switches	Applicable Accessories					
Enabling	Series	Description				
Switches y Products		Nameplate: HWAM, HWAQ, HWAS, HWAV-□				
osion Proof		Marking plate for nameplate: HWNP-□				
inal Blocks		Anti-rotation ring: HW9Z-RL				
& Sockets	HW Series	EMO switch guard: HW9Z-KG3, HW9Z-KG4				
Circuit Protectors		Switch guard: HW9Z-K1, HW9Z-K11				
er Supplies		Pushbutton clear boot:				
lumination		OC-31, OC-32 Padlock cover:				
Controllers		HW9Z-KL1				
Operator Interfaces	YW Sorioo	Nameplate: HWAV-□				
Sensors	XW Series Emergency	EMO switch guard: HW9Z-KG3, HW9Z-KG4				
AUTO-ID	Stop Switches	Anti-rotation ring: HW9Z-RL				
		Nameplate: NWA-□, NWAQ-□, NWAS-0, NWAL-0, NWAQL-0, NWAV-□				
FB		Anti-rotation ring: OGL-31				
	TW Series	Metal protector: OLW-C				
		Pushbutton clear boot: 0C-31, 0C-32				
		Button cover: OCW-10*, OCW-11*				
		Padlock cover: HW9Z-KL1, HS9Z-PC22				

Note: Confirm the specifications of boxes, switches/pilot lights, and accessories before choosing accessories, referring to separate catalogs.

## **Mounting Hole Dimensions**



Note: For contact cover boxes, see C-019.

## **Applicable DIN Rail**

Description	Material	Part No.	Ordering No.
DIN Rail	Aluminum	BAA1000	BAA1000PN10
	Steel	BAP1000	BAP1000PN10
End Clip	Steel	BNL6	BNL6PN10

Note: Use DIN rail adapters FB9Z-PK3 when installing a DIN in the control box. See H-071 for DIN rail products.

## **Applicable Terminal Block / Transformer**

	Series / Part No.				
Terminal Block	BN-W / BNH-W / BN1U BN10W, BN15MW, BN15LW, BN30W BNH10W, BNH15MW, BNH15LW, BNH30W BN1U-16W, BN1U-20W, BN1U-40W				
	BA BA111T, BA211T, BA311T				
Separate Mounting Transformer TWR5**					

Note: Install the terminal blocks and separate mounting transformers on a DIN rail using two DIN rail adapters (FB9Z-PK3). Choose the types and quantity of terminal blocks, transformers, end clips, and enclosures carefully taking the specifications into consideration. The separate mounting transformer can be installed on a DIN rail adapter directly.

# **Control Boxes**

APEM

Switches & Pilot Lights

Control Boxes
Emergency Stop Switches
Enabling Switches
Safety Products
Explosion Proof
Terminal Blocks

Relays & Sockets

## 1 Hole (Box Size: 76mm)

**Control Stations** 

Symbols of Switches

Item

**Emergency Stop Switches** 

Pushbuttons

Pilot Lights

Selector Switches

**Key Selector Switches** 

Symbols

(ES)

PB

(PL)

S

	Box Size: 76mm)							Circuit
Symbols	Specification		Legend	<without nameplate=""></without>		With nameplate "EMERGENCY STO	P"	Protectors
		Switch Part No.	Contact Configuration	Part No. (Ordering Part No.)	Color (*)	Part No. (Ordering Part No.)	Color (*)	Power Supp
			1NC	FB1W-XW1E-BV401MRH-Y0		FB1W-XW1E-BV401MRH-Y1		Controllers
			2NC	FB1W-XW1E-BV402MRH-Y0		FB1W-XW1E-BV402MRH-Y1		Operator Interfaces
	XW Series Emergency Stop		3NC	FB1W-XW1E-BV403MRH-Y0		FB1W-XW1E-BV403MRH-Y1		Sensors
	Switches (Non-illuminated, pushlock pull or turn reset)		4NC	FB1W-XW1E-BV404MRH-Y0		FB1W-XW1E-BV404MRH-Y1		AUTO-ID
		XW1E-BV4	1N01NC	FB1W-XW1E-BV411MRH-Y0	RH	FB1W-XW1E-BV411MRH-Y1	- RH	
			1N02NC	FB1W-XW1E-BV412MRH-Y0		FB1W-XW1E-BV412MRH-Y1		FB
			1NO3NC	FB1W-XW1E-BV413MRH-Y0		FB1W-XW1E-BV413MRH-Y1		
			2N02NC	FB1W-XW1E-BV422MRH-Y0		FB1W-XW1E-BV422MRH-Y1		
ES		hes (Illuminated LED/24V	1NC	FB1W-XW1E-LV401Q4MR-Y0	_	FB1W-XW1E-LV401Q4MR-Y1		
			2NC	FB1W-XW1E-LV402Q4MR-Y0		FB1W-XW1E-LV402Q4MR-Y1		
			3NC	FB1W-XW1E-LV403Q4MR-Y00		FB1W-XW1E-LV403Q4MR-Y1		
	XW Series Emergency Stop Switches (Illuminated, LED/24V,		4NC	FB1W-XW1E-LV404Q4MR-Y0		FB1W-XW1E-LV404Q4MR-Y1		
	pushlock pull or turn reset)	XW1E-LV4	1N01NC	FB1W-XW1E-LV411Q4MR-Y0	R	FB1W-XW1E-LV411Q4MR-Y1	— R	
			1N02NC	FB1W-XW1E-LV412Q4MR-Y0		FB1W-XW1E-LV412Q4MR-Y1		
			1NO3NC	FB1W-XW1E-LV413Q4MR-Y0	1	FB1W-XW1E-LV413Q4MR-Y1		
			2N02NC	FB1W-XW1E-LV422Q4MR-Y0	1	FB1W-XW1E-LV422Q4MR-Y1		
	XW Series Emergency Stop Switches	XW1E-TV4	3NC	FB1W-XW1E-TV403Q4MR-Y0	Р	FB1W-XW1E-TV403Q4MR-Y1	P	
	(Push-ON LED, LED/24V,pushlock pull or turn reset)	AWIE-1V4	1N02NC	FB1W-XW1E-TV412Q4MR-Y0	R	FB1W-XW1E-TV412Q4MR-Y1	— R	

Color code (\*): Red (R), Bright Red (RH)

## Legend / Guard

Legend / Guard		Nameplate Part No.	Guard / Marking Plate Part No.	
	<0ptional marking plate>	HWAM	-	
E-STOP Nameplate	<yellow -="" blank=""></yellow>	HWAV-0	-	
Namoplato	EMERGENCY-STOP	HWAV-27	-	
	ON	HWAM	HWNP-1	
	OFF	HWAM	HWNP-2	
	START	HWAM	HWNP-3	
Nameplate	STOP	HWAM	HWNP-4	
	OFF-ON	HWAM	HWNP-31	
	HAND-AUTO	HWAM	HWNP-35	
	HAND-OFF-AUTO	HWAM	HWNP-53	
Guard	HW9Z-KG4	-	HW9Z-KG4	
	HW9Z-KG3	-	HW9Z-KG3	

bownload catalogs and CAD from http://eu.idec.com/downloads

## Power Supplies LED Illumination

C-010

## **Control Stations**

## 1 Hole (Box Size: 76mm)

S.										
	Symbol	Specification		Legend	<without nameplate=""></without>		With nameplate "EMERGENCY"stop	)		
			Switch Part No.	Contact Configuration	Part No. (Ordering Part No.)	Color (*)	Part No. (Ordering Part No.)	Color (*)		
APEM		HW Series Emergency Stop Switches		1NC	FB1W-HW1B-V401R-Y0		FB1W-HW1B-V401R-Y1			
Switches & Pilot Lights		(Pushlock turn reset)	HW1B-V4	2NC	FB1W-HW1B-V402R-Y0	R	FB1W-HW1B-V402R-Y1	R		
Control Boxes				1NO1NC	FB1W-HW1B-V411R-Y0		FB1W-HW1B-V411R-Y1			
Emergency Stop Switches Enabling	ES			1NC	FB1W-HW1B-Y201R-Y0		FB1W-HW1B-Y201R-Y1			
Switches Safety Products			Switches	- Switches HW1E	HW1B-Y2	2NC	FB1W-HW1B-Y202R-Y0	R	FB1W-HW1B-Y202R-Y1	R
Explosion Proof				1N01NC	FB1W-HW1B-Y211R-Y0	1	FB1W-HW1B-Y211R-Y1			
Terminal Blocks	Switche			1NC	FB1W-HW1B-X401R-Y0		FB1W-HW1B-X401R-Y1			
Relays & Sockets		HW Series Emergency Stop Switches	HW1B-X4	2NC	FB1W-HW1B-X402R-Y0	R	FB1W-HW1B-X402R-Y1	R		
Circuit Protectors		(Pushlock key reset)		1NO1NC	FB1W-HW1B-X411R-Y0		FB1W-HW1B-X411R-Y1			
Power Supplies	Color code (*)	r Bed (B)	I	1						

Color code (\*): Red (R) LED Illumination

## Control Stations with SEMI Emergency off (EMO) Switches

Operator Interfaces	Symbol	Specification		Guard	<without guard=""></without>		SEMI Switchguard		
Sensors			Switch Part No.	Contact Configuration	Part No. (Ordering Part No.)	Color (*)	Part No. (Ordering Part No.)	Color (*)	
AUTO-ID		HW Series SEMI EMO Pushbutton		1NC	FB1W-HW1B-V401R-EMO-Y0		FB1W-HW1B-V401R-EM0-Y□		
		(Pushlock turn reset)	HW1B-V4	2NC	FB1W-HW1B-V402R-EMO-Y0	R	FB1W-HW1B-V402R-EM0-Y□	R	
FB				1N01NC	FB1W-HW1B-V411R-EMO-Y0		FB1W-HW1B-V411R-EMO-Y□		
				1NC	FB1W-XW1E-BV401MRH-EM0-Y0		FB1W-XW1E-BV401MRH-EM0-Y		
	ES			2NC	FB1W-XW1E-BV402MRH-EM0-Y0		FB1W-XW1E-BV402MRH-EM0-Y		
	(For SEMI)			3NC	FB1W-XW1E-BV403MRH-EM0-Y0		FB1W-XW1E-BV403MRH-EMO-Y		
		XW Series SEMI EMO Pushbuttons	XW1E-BV4	4NC	FB1W-XW1E-BV404MRH-EM0-Y0	RH	FB1W-XW1E-BV404MRH-EM0-Y	BH	
		(Non-illuminated, pushlock pull or turn reset)	AWIL-DV4	1N01NC	FB1W-XW1E-BV411MRH-EMO-Y0	nii	FB1W-XW1E-BV411MRH-EMO-Y		
				1N02NC	FB1W-XW1E-BV412MRH-EM0-Y0		FB1W-XW1E-BV412MRH-EMO-Y		
			1NO3NC	FB1W-XW1E-BV413MRH-EMO-Y0		FB1W-XW1E-BV413MRH-EMO-Y			
				2N02NC	FB1W-XW1E-BV422MRH-EM0-Y0		FB1W-XW1E-BV422MRH-EMO-Y		

Color code (\*): Red (R), Bright Red (RH)

\*1) Specify a code for SEMI switchguard in place of 🗖 in the part no. (2: HW9Z-KG3, 3: HW9Z-KG4) Control stations with HW9Z-KG3, HW9Z-KG4 are SEMI S2 compliant. For details, see D-052.

#### **Control Stations**















With HW1B-V4

With HW1B-V4 & HW9Z-KG3

With HW1B-V4 & HW9Z-KG4

With XW1E-BV4

With XW1E-BV4 & HW9Z-KG3

With XW1E-BV4 & HW9Z-KG4

For more information, visit http://eu.idec.com

C-011

**Control Boxes** 

Controllers

**Control Boxes** 

Terminal Blocks Relays & Sockets

## **Control Stations**

## 1 Hole (Box Size: 76mm)

-	=							
Symbol	Specification		Legend	<without nameplate=""></without>		<optional marking="" plate=""></optional>		
		Switch Part No.	Contact Configuration	Part No. (Ordering Part No.)	Color (*)	Part No. (Ordering Part No.)	Color (*)	
1	Pushbutton (Momentary,flush)		1N0	FB1W-HW1B-M110*-Z0	G	FB1W-HW1B-M110*-Z1	G	APEM
	HW1B-M1	1N01NC	FB1W-HW1B-M111*-Z0	Ŵ	FB1W-HW1B-M111*-Z1	Ŵ	Switches & Pilot Lights	
PB		HW1B-M2	1NC	FB1W-HW1B-M201*-Z0		FB1W-HW1B-M201*-Z1	R	Control Boxes
9	Pushbutton (Momentary, extended)				R			Emergency Stop Switches
	(womentary, extended)		1N01NC	FB1W-HW1B-M211*-Z0		FB1W-HW1B-M211*-Z1		Enabling Switches
	Pushbutton	Pushbutton	1N0	FB1W-HW1B-M410*-Z0	G	FB1W-HW1B-M410G-Z1 FB1W-HW1B-M411G-Z1		Safety Products
1	(Momentary, ø40)	HW1B-M4	1N01NC	FB1W-HW1B-M411G-Z0				Explosion Proof

Color code (\*): Black (B), Green (G), Red (R), White (W)

Symbol	Specification		Legend	With nameplate "ON"		With nameplate "START"		Circuit Protectors
		Switch Part No.	Contact Configuration	Part No. (Ordering Part No.)	Color (*)	Part No. (Ordering Part No.)	Color (*)	Power Supplies
Pushbutton (Momentary,flush)		1N0	FB1W-HW1B-M110*-Z2		FB1W-HW1B-M110*-Z3		LED Illumination	
		HW1B-M1			G		G	Controllers
PB			1NO1NC	FB1W-HW1B-M111*-Z2	W	vv	FB1W-HW1B-M111*-Z3	W
	Pushbutton	I HW18-M4	1N0	FB1W-HW1B-M410G-Z2		FB1W-HW1B-M410G-Z3		Sensors
	(Momentary, ø40)		1N01NC	FB1W-HW1B-M411G-Z2	G	FB1W-HW1B-M411G-Z3	G	AUTO-ID
			INOTINO	FBTW-HWTB-M4TTG-Z2		101W-1W10-W4110-23		AUTU-ID

Color code (\*): Green (G), White (W)

Symbol	Specification		Legend	With nameplate "OFF"		With nameplate "STOP"		
		Switch Part No.	Contact Configuration	Part No. (Ordering Part No.)	Color (*)	Part No. (Ordering Part No.)	Color (*)	
PB	PB Pushbutton (Momentary, extended)	HW1B-M2	1NC	FB1W-HW1B-M201*-Z2	R	FB1W-HW1B-M201*-Z3	R	]
			1N01NC	FB1W-HW1B-M211*-Z2	В	FB1W-HW1B-M211*-Z3	В	

Color code (\*): Black (B), Red (R)

Symbol	Specification		Legend		With "I&ON/0&OFF" on Switch		
		Switch Part No.	Contact Configuration		Part No. (Ordering Part No.)	Color (*)	
	Dual Pushbutton		Top Button	Bottom Buttton	r art no. (ordoning r art no.)		
PB	(Momentary, flush–extended)	HW7D-B12	1N0	1NC	FB1W-HW7D-B121001WB1-Z0	WB (Top: White / Bottom: Black)	
	Dual Pushbutton (Interlock, flush-extended)	HW/11-B22		1NC	FB1W-HW7D-B221001WB1-Z0	WB (Top: White / Bottom: Black)	

Symbol	Specification		Legend	<without nameplate=""></without>					
		Switch Part No.	Illuminated Voltage	Part No. (Ordering Part No.)	Color (*)	Part No. (Ordering Part No.)	Color (*)		
PL	Pilot Light	HW1P-2Q (Round extended)	LED / 24V	FB1W-HW1P-2Q4*-Z0	Color 1	FB1W-HW1P-2Q4*-Z0	PW S		
		HW1P-5Q (Dome)	LED / 24V	FB1W-HW1P-5Q4*-Z0	Color 1	FB1W-HW1P-5Q4*-Z0	PW S		

(Color 1) R ,G, A, Y

Color code (\*): Red (R), Green (G), Amber (A), Yellow (Y), Pure White (PW), Blue (S)

## **Control Stations**

## 1 Hole (Box Size: 76mm)

Symbol	Specification		Legend	<without nameplate=""></without>	<optional marking="" plate=""></optional>	
	Selector Switches	Switch Part No.	Contact Configuration	Part No. (Orde	ing Part No.)	
	(2-position maintained, knob, black)	HW1S-2T	1N0	FB1W-HW1S-2T10-Z0	FB1W-HW1S-2T10-Z1	
SS			1N01NC	FB1W-HW1S-2T11-Z0	FB1W-HW1S-2T11-Z1	
	Selector Switches		1N0	FB1W-HW1K-2A10-Z0	FB1W-HW1K-2A10-Z1	
	(2-position maintained, knob, key selector) (*1)	HW1K-2A	1N01NC	FB1W-HW1K-2A11-Z0	FB1W-HW1K-2A11-Z1	

\*1) Keys removable in both left and right.

Explosion Proof			~					
Terminal Blocks	Symbol	Specification		Legend	With nameplate "ON-OFF"	With nameplate "HAND-AUTO"		
Relays & Sockets		Selector Switches (2-position maintained, knob, black)	Switch Part No.	Contact Configuration	Part No. (Ordering Part No.)			
Circuit Protectors			HW1S-2T	1N0	FB1W-HW1S-2T10-Z2	FB1W-HW1S-2T10-Z3		
Power Supplies	SS			1N01NC	FB1W-HW1S-2T11-Z2	FB1W-HW1S-2T11-Z3		
LED Illumination		Selector Switches		1N0	FB1W-HW1K-2A10-Z2	FB1W-HW1K-2A10-Z3		
Controllers		(2-position maintained, knob, key selector) (*1)	HW1K-2A	100100				
Operator Interfaces	*4) 1/	vable in both left and right		1NO1NC	FB1W-HW1K-2A11-Z2	FB1W-HW1K-2A11-Z3		

\*1) Keys removable in both left and right.

Symbol	Specification		Legend	<without nameplate=""></without>	<optional marking="" plate=""></optional>
Selector Switches (3-position maintained, knob,		Switch Part No.	Contact Configuration	Part No. (Orde	pring Part No.)
	black)		2N0	FB1W-HW1S-3T20-Z0	FB1W-HW1S-3T20-Z1

Symbol	Specification		Legend	With nameplate "HAND-OFF-AUTO"
(SS)	Selector Switches (3-position maintained, knob,	Switch Part No.	Contact Configuration	Part No. (Ordering Part No.)
	black)	HW1S-3T	2N0	FB1W-HW1S-3T20-Z2

## 2 Holes (Box Size: 140mm, Mounting Centers: 50mm)

Symbol	Specification		Legend ①	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "ON"	With nameplate "START"		
Symbol	Specification		Legend 2	<without nameplate=""></without>	<0ptional marking plate>	With nameplate "OFF"	With nameplate "STOP"		
	<ul> <li>①Pushbutton (Momentary, flush, green)</li> <li>②Pushbutton (Momentary, flush, red)</li> </ul>	Switch Part No.	Contact Configuration	Part No. (Ordering Part No.)					
0 <b>PB</b>		HW1B-M1 HW1B-M1	1N0 1N0	FB2W-211Z-A02001	-	-	-		
2 <b>PB</b>			1N0 1NC	FB2W-211Z-A02002	FB2W-211Z-A02003	FB2W-211Z-A02004	FB2W-211Z-A02005		
			1N01NC 1N01NC	FB2W-211Z-A02006	FB2W-211Z-A02007	FB2W-211Z-A02008	FB2W-211Z-A02009		

Cumbol	Creation	$\searrow$	Legend	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "ON"	With nameplate "START"			
Symbol	Specification		Legend@	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "OFF"	With nameplate "STOP"			
		Switch Part No.	Contact Configuration		Part No. (Ordering Part No.)					
	①Pushbutton (Momentary, flush, white)	HW1B-M1 HW1B-M1	1N0 1N0	FB2W-211Z-A02010	-	_	-			
© (PB)	<pre>@Pushbutton (Momentary, flush, black)</pre>		1N0 1NC	FB2W-211Z-A02011	FB2W-211Z-A02012	FB2W-211Z-A02013	FB2W-211Z-A02014			
			1N01NC 1N01NC	FB2W-211Z-A02015	FB2W-211Z-A02016	FB2W-211Z-A02017	FB2W-211Z-A02018			

APEM Switches & Pilot Lights

Emergency Stop Switches Enabling Switches

Safety Products

Sensors AUTO-ID

## **Control Stations**

## 2 Holes (Box Size: 140mm, Mounting Centers: 50mm)

		<b>`</b>	· J		,					
ſ	Symbol	Specification	$\backslash$	Legend ①	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "ON"	With nameplate "START"		
	Symbol	Specification		Legend@	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "OFF"	With nameplate "STOP"		
		<ul> <li>①Pushbutton (Momentary, flush, green)</li> <li>②Pushbutton</li> </ul>		Contact		Part No. (Ordering Part No.)				
	$\square$			Configuration	ionfiguration					
			HW1B-M1	1N0 1NC	FB2W-211Z-A02019	FB2W-211Z-A02020	FB2W-211Z-A02021	FB2W-211Z-A02022	APEM	
	© (PB)	(Momentary, extended, red)		-					Switches &	
		(monitoritary, externed, red)	HW1B-M2	1N01NC 1N01NC	FB2W-211Z-A02023	FB2W-211Z-A02024	FB2W-211Z-A02025	FB2W-211Z-A02026	Pilot Lights	
				INUTING						

								Emergency Stop Switches
Symbol	Specification		Legend	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "ON"	With nameplate "START"	Enabling
Symbol	Specification		Legend@	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "OFF"	With nameplate "STOP"	Switches
	<ul> <li>Pushbutton (Momentary, flush, white)</li> <li>Pushbutton (Momentary, extended, red)</li> </ul>		Contact Configuration		Safety Products			
		HW1B-M1	1N0 1NC	FB2W-211Z-A02027	FB2W-211Z-A02028	FB2W-211Z-A02029	FB2W-211Z-A02030	Explosion Proof
2 (PB)		HW1B-M2	1N01NC	FB2W-211Z-A02031	FB2W-211Z-A02032	FB2W-211Z-A02033	FB2W-211Z-A02034	Terminal Blocks
			1N01NC	1 DZW-2112-A02031	1 DZW-2112-A02032	1 DZW-2112-A02033	1 DZW-2112-A02034	Relays & Sockets

									Circuit
ĺ	Cumbol	Specification	$\sim$	Legend ①	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "ON"	With nameplate "START"	Protectors
	Symbol	opecification		Legend@	<without nameplate=""></without>	<0ptional marking plate>	With nameplate "OFF"	With nameplate "STOP"	Power Supplies
				Contact		Part No. (Orde			
		<ul><li>①Pushbutton (Momentary, flush, white)</li><li>②Pushbutton</li></ul>	Switch Part No.	Configuration		LED Illumination			
	0 (PB) 2 (PB)		HW1B-M1	1NO 1NC	FB2W-211Z-A02035	FB2W-211Z-A02036	FB2W-211Z-A02037	FB2W-211Z-A02038	Controllers
	G	(Momentary, ø40, black)	HW1B-M4	1N01NC 1N01NC	FB2W-211Z-A02039	FB2W-211Z-A02040	FB2W-211Z-A02041	FB2W-211Z-A02042	Operator Interfaces

Symbol	Specification		Legend ①	<without nameplate=""></without>
Symbol	opecification		Legend@	<without nameplate=""></without>
0 PL	①Pilot Light (Round extended, red)	Switch Part No.	Illuminated Voltage	Part No. (Ordering Part No.)
2 PL	②Pilot Light (Round extended, green)	HW1P-2Q HW1P-2Q	LED / 24V LED / 24V	FB2W-211Z-A02043

Symbol	Specification		Legend ①	<without nameplate=""></without>	<without nameplate=""></without>	<without nameplate=""></without>
Symbol			Legend@	<without nameplate=""></without>	<0ptional marking plate>	With nameplate "STOP"
0 PL	①Pilot Light (Round extended, red)	Switch Part No.	Illuminated Voltage Contact Configuration		Part No. (Ordering Part No.)	
2 PB	②Pilot Light (Momentary, extended,black)	HW1P-2Q HW1B-M2	LED / 24V 1N01NC	FB2W-211Z-A02045	FB2W-211Z-A02046	FB2W-211Z-A02047

Symbol	Specification	$\sim$	Legend	<without nameplate=""> <without nameplate=""> <without name<="" th=""></without></without></without>		
Symbol			Legend@	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "HAND-AUTO"
0 PL	<ul> <li>Pilot Light (Round extended, red)</li> <li>Selector Switch (2-position maintained, knob, black)</li> </ul>	Switch Part No.	Illuminated Voltage Contact Configuration	Part No. (Ordering Part No.)		
2 ŠŠ		HW1P-2Q HW1S-2T	LED / 24V 1N01NC	FB2W-211Z-A02048	FB2W-211Z-A02049	FB2W-211Z-A02050

Symbol	Specification		Legend	<without nameplate=""> <without nameplate=""> <without namep<="" th=""></without></without></without>		
Symbol			Legend@	<without nameplate=""></without>	<0ptional marking plate>	With nameplate "HAND-AUTO"
0 PL	<ul> <li>①Pilot Light         <ul> <li>(Round extended, red)</li> <li>②Selector Switch (*1)</li> <li>(2-position maintained, key selector)</li> </ul> </li> </ul>	Switch Part No.	Illuminated Voltage Contact Configuration			
2 <u>S</u>		HW1P-2Q HW1K-2A	LED / 24V 1N01NC	FB2W-211Z-A02051	FB2W-211Z-A02052	FB2W-211Z-A02053

 $^{\ast}$  1) Keys removable in both left and right.

**Control Boxes** 

Sensors

## **Control Stations**

## 3 Holes (Box Size: 140mm, Mounting Centers: 30mm)

	Symbol Specification		Legend (1)	<without nameplate=""></without>	<optional marking="" plate=""></optional>	
	Symbol Specification		Legend	<without nameplate=""></without>	<optional marking="" plate=""></optional>	
	0 2 3		Legend 3	<without nameplate=""></without>	<0ptional marking plate>	
APEM	PBPBPB	Switch Part No.	Contact Configuration	Part No. (Ordering Part No.)		
Switches & Pilot Lights	<ul> <li>①Pushbutton (Momentary, flush, green)</li> <li>②Pushbutton (Momentary, flush, red)</li> <li>③Pushbutton (Momentary, flush, green)</li> </ul>	HW1B-M1 HW1B-M1 HW1B-M1	1NO 1NC 1NO	FB2W-312Z-A03001	FB2W-312Z-A03002	
Control Boxes						

Emergency						
Stop Switches	Symbol Specification		Legend ①	<without nameplate=""></without>	<optional marking="" plate=""></optional>	
Enabling	Symbol Specification		Legend	<without nameplate=""></without>	<optional marking="" plate=""></optional>	
Switches	0 2 3		Legend ③	<without nameplate=""></without>	<optional marking="" plate=""></optional>	
Safety Products	PBPBPB	Switch Part No.	Contact Configuration	Part No. (Ordering Part No.)		
Explosion Proof	①Pushbutton (Momentary, flush, white)	HW1B-M1	1N0	500W 0407 400000	50000 0107 400004	
Terminal Blocks	<ul> <li>②Pushbutton (Momentary, flush, red)</li> <li>③Pushbutton (Momentary, flush, black)</li> </ul>	HW1B-M1 HW1B-M1	1NC 1NO	FB2W-312Z-A03003	FB2W-312Z-A03004	

Circuit	Symbol Specification	$\overline{\ }$	Legend	<without nameplate=""></without>	<without nameplate=""></without>	<without nameplate=""></without>	<without nameplate=""></without>
Protectors	Symbol Specification		Legend@	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "ON"	With nameplate "START"
Power Supplies	0 2 3		Legend3	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "OFF"	With nameplate "STOP"
		Curitals David Na	Illuminated Voltage		Dant Na. (Orda	vive Devit Ne )	
LED Illumination		Switch Part No.	Contact Configuration		ring Part No.)		
	Deliot Light (Round extended, red)	HW1P-2Q	LED / 24V				
Controllers	②Pushbutton (Momentary, flush, red)	HW1B-M1	1N0	FB2W-312Z-A03005	FB2W-312Z-A03006	FB2W-312Z-A03007	FB2W-312Z-A03008
operator	③Pushbutton (Momentary, extended, black)	HW1B-M2	1NC				
Interfaces							

#### 3 Holes (Box Size: 200mm, Mounting Centers: 50mm) AUTO-ID

Symbol	Specification		Legend	<without nameplate=""></without>	<optional marking="" plate=""></optional>
Symbol	Specification		Legend	<without nameplate=""></without>	<optional marking="" plate=""></optional>
			Legend3	<without nameplate=""></without>	<optional marking="" plate=""></optional>
	①Pushbutton	Switch Part No.	Contact Configuration	Part No. (Ordering Part No.)	
	(Momentary, flush, green) ②Pushbutton (Momentary, flush, red) ③Pushbutton	HW1B-M1 HW1B-M1	1N0 1NC 1N0	FB3W-311Z-A03009	FB3W-311Z-A03010
	(Momentary, flush, green)	HW1B-M1	1N01NC 1N01NC 1N01NC	FB3W-311Z-A03011	FB3W-311Z-A03012

Symbol	Specification		Legend ①	<without nameplate=""></without>	<optional marking="" plate=""></optional>
Symbol	Specification		Legend	<without nameplate=""></without>	<optional marking="" plate=""></optional>
			Legend3	<without nameplate=""></without>	<0ptional marking plate>
	<ul> <li>Pushbutton (Momentary, flush, white)</li> <li>Pushbutton (Momentary, flush, red)</li> <li>Pushbutton (Momentary, flush, black)</li> </ul>	Switch Part No.	Contact Configuration	Part No. (Ordering Part No.)	
<ul> <li>PB</li> <li>PB</li> <li>PB</li> <li>PB</li> </ul>		HW1B-M1 HW1B-M1	1N0 1NC 1N0	FB3W-311Z-A03013	FB3W-311Z-A03014
		HW1B-M1	1N01NC 1N01NC 1N01NC	FB3W-311Z-A03015	FB3W-311Z-A03016

Cumbol	Creation	$\smallsetminus$	Legend ①	<without nameplate=""></without>	With nameplate "ON"	With nameplate "START"
Symbol	Symbol Specification		Legend@	<without nameplate=""></without>	With nameplate "OFF"	With nameplate "STOP"
	①Pushbutton		Legend3	<none> (with yellow blank nameplate)</none>	With nameplate"EMERGENCY-STOP"	With nameplate"EMERGENCY-STOP"
	① (PB) (Momentary, flush, white)		Contact Configuration	Part No. (Ordering Part No.)		
	(Momentary, flush, black) ③Emergency Stop Switch (Pushlock turn reset)	HW1B-M1 HW1B-M2 HW1B-V4	1N0 1NC 2NC	FB3W-311Z-A03017	FB3W-311Z-A03018	FB3W-311Z-A03019

Relays & Sockets

Sensors

## **Control Stations**

## 3 Holes (Box Size: 140mm, Mounting Centers: 30mm)

Symbol	Specification		Legend ①	<without nameplate=""></without>	With nameplate "ON"	With nameplate "START"
Symbol	Specification		Legend@	<without nameplate=""></without>	With nameplate "OFF"	With nameplate "STOP"
			Legend3	<none> (with yellow blank nameplate)</none>	With nameplate "EMERGENCY-STOP"	With nameplate"EMERGENCY-STOP"
	Switch Part No.	Contact Configuration		Part No. (Ordering Part No.)	1	
2 PB	<ul> <li>PB</li> <li>(Momentaly, hush, white)</li> <li>Pushbutton</li> <li>(Momentary, extended, black)</li> </ul>	HW1B-M1 HW1B-M2	1N01NC 1N01NC 2NC	FB3W-311Z-A03020	FB3W-311Z-A03021	FB3W-311Z-A03022
3 ES (3 Emergency Stop Switch (Pushlock pull or turn reset)	XW1E-BV4	1N01NC 1N01NC 1N02NC	FB3W-311Z-A03026	FB3W-311Z-A03027	FB3W-311Z-A03028	

Symbol	Specification		Legend ①	<without nameplate=""></without>	With nameplate "ON"	With nameplate "START"
Symbol	opecilication		Legend@	<without nameplate=""></without>	With nameplate "OFF"	With nameplate "STOP"
		$\sim$	Legend3	<none> (with yellow blank nameplate)</none>	With nameplate "EMERGENCY-STOP"	With nameplate"EMERGENCY-STOP"
			Illuminated Voltage Contact Configuration	Part No. (Ordering Part No.)		
<ul> <li>(Momentary, nush, white)</li> <li>(PB)</li> <li>(PB)</li> <li>(PB)</li> <li>(PB)</li> <li>(Pushbutton (Momentary, extended, black)</li> <li>(Pushlock pull or turn reset)</li> </ul>	HW1B-M1 HW1B-M2	2NC/LED/24V 1N01NC 1N01NC	FB3W-311Z-A03023	FB3W-311Z-A03024	FB3W-311Z-A03025	
	XW1E-LV4	1NO2NC/LED/24V 1NO1NC 1NO1NC	FB3W-311Z-A03029	FB3W-311Z-A03030	FB3W-311Z-A03031	

Symbol	Specification		Legend ①	<without nameplate=""></without>	<without nameplate=""></without>	<without nameplate=""></without>	<without nameplate=""></without>	Contro
Symbol	Specification		Legend@	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "ON"	With nameplate "START"	Operat
			Legend3	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "OFF"	With nameplate "STOP"	Interfac
	© Pilot Light		Illuminated Voltage Contact Configuration					
Image: Constraint of the second se	HW1P-2Q HW1B-M1	LED / 24V 1N0 1NC	FB3W-311Z-A03032	FB3W-311Z-A03033	FB3W-311Z-A03034	FB3W-311Z-A03035	AUT0-	
3 <b>PB</b>	(Momentary, extended, black)	HW1B-M2	LED / 24V 1N01NC 1N01NC	FB3W-311Z-A03036	FB3W-311Z-A03037	FB3W-311Z-A03038	FB3W-311Z-A03039	FB

Symbol	Specification		Legend ①	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "ON"	With nameplate "START"
Symbol	opecification		Legend@	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "OFF"	With nameplate "STOP"
			Legend3	<without nameplate=""></without>	<0ptional marking plate>	With nameplate "HAND-AUTO"	With nameplate "HAND-AUTO"
0 (PB)	①Pilot Light	Switch Part No.	Contact Configuration		Part No. (Orde	ering Part No.)	
Image: Second system     Image: Second system       Image: Second system     Ima	HW1B-M1	1NO 1NC 1NO	FB3W-311Z-A03041	FB3W-311Z-A03042	FB3W-311Z-A03044	FB3W-311Z-A03043	
3 5	(2-nosition knob black)	HW1B-M2 HW1S-2T	1N01NC 1N01NC 1N01NC	FB3W-311Z-A03045	FB3W-311Z-A03046	FB3W-311Z-A03048	FB3W-311Z-A03047

**Control Boxes** 

## APEM

Switches & Pilot Lights

Emergency Stop Switches

Enabling Switches

Safety Products

Explosion Proof

Terminal Blocks

Relays & Sockets

Circuit Protectors Power Supplies

LED Illumination

Controllers
Operator nterfaces
Sensors
AUTO-ID

## **Control Stations**

## 4 Holes (Box Size: 200mm, Mounting Centers: 36mm)

Symbol Specification		Legend	<without nameplate=""></without>	<without nameplate=""></without>	<without nameplate=""></without>
Symbol Specification		Legend@	<without nameplate=""></without>	<without nameplate=""></without>	<without nameplate=""></without>
		Legend3	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "ON"
0 2 3 4		Legend ④	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "OFF"
PL PL PB PB	Switch Part No.	Illuminated Voltage Contact Configuration	Part No. (Ordering Part No.)		
①Pilot Light (Round extended, red)	HW1P-2Q	LED / 24V			
③Pushbutton (Momentary, flush, white)	HW1P-2Q HW1B-M1	1N01NC	FB3W-413Z-A04001	FB3W-413Z-A04002	FB3W-413Z-A04003
@Pushbutton (Momentary, extended, black)	HW1B-M2	1NU1NC			
	©Pilot Light (Round extended, red) ©Pilot Light (Round extended, green)	O 2 3      O     PLPPPP     PBP     Switch Part No.     PPlot Light (Round extended, red)     Pilot Light (Round extended, green)     Pushbutton (Momentary, flush, white)     HW1P-2Q     HW1P-2Q     HW1B-M1	Symbol Specification       Legend@         ① ② ③ ④       Legend④         ① PIOL Light (Round extended, red)       Switch Part No.       Illuminated Voltage Contact Configuration         ① Pilot Light (Round extended, green)       HW1P-2Q       LED / 24V         ③ Pushbutton (Momentary, flush, white)       HW1B-M1       1N01NC	Symbol Specification       Legend (2) <without nameplate="">         ① ② ③ ④       Legend (3)       <without nameplate="">         ① PL PL PB PB       Switch Part No.       Illuminated Voltage Contact Configuration         ① Pliot Light (Round extended, red)       Without nameplate&gt;       HW1P-2Q         ② Pushbutton (Momentary, flush, white)       HW1P-2Q       LED / 24V         HW1B-M1       1N01NC       FB3W-413Z-A04001</without></without>	Symbol Specification       Legend@ <without nameplate="">         ①       ②       ③          ①       ②       ③          ②       ③           ②       ③           ②       ③           ②       ③           ②       ③           ②       ③           ②       ③           ②       ③           ②       ③           ②       ③           ③       Ø           Ø       PD(PD(PB)(PB)       B)          Switch Part No.       Illuminated Voltage Contact Configuration       Part No. (Ordering Part No.)         Ø       Pilot Light (Round extended, green)        HW1P-2Q       LED / 24V HW1P-2Q       FB3W-413Z-A04001         PB3W-413Z-A04002       HW1B-M1       1N01NC       FB3W-413Z-A04001       FB3W-413Z-A04002</without>

Enabling						
Switches	Symbol Specification		Legend	<without nameplate=""></without>	<without nameplate=""></without>	<without nameplate=""></without>
	Symbol Specification		Legend@	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "ON"
Safety Products	0 2 3 4		Legend3	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "OFF"
Explosion Proof			Legend@	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "HAND-AUTO"
Explosion 1100	PLPBPBSS	Switch Part No.	Illuminated Voltage		Part No. (Ordering Part No.)	
Terminal Blocks		SWILLII FAILINU.	Contact Configuration		rait No. (Ordening rait No.)	
	①Pilot Light (Round extended, red)					
Relays & Sockets	<ul> <li>② Pushbutton (Momentary, flush, white)</li> <li>③ Pushbutton (Momentary, extended, black)</li> </ul>	HW1P-2Q HW1B-M1	LED / 24V 1N01NC	FB3W-413Z-A04004	FB3W-413Z-A04005	FB3W-413Z-A04006
Circuit Protectors	<ul> <li>Selector Switch (2-position maintained, knob, black)</li> </ul>	HW1B-M2 HW1S-2T	1N01NC 1N01NC	FD3W-413Z-A04004	TB3W-4132-A04003	FD3W-4132-A04000
Power Supplies						]

#### 5 Holes (Box Size: 200mm, Mounting Centers: 30mm) LED Illumination

	Symbol Specification	$\backslash$	Legend	<without nameplate=""></without>	<without nameplate=""></without>	<without nameplate=""></without>
Controllers	Symbol Specification		Legend@	<without nameplate=""></without>	<without nameplate=""></without>	<without nameplate=""></without>
Operator			Legend 3	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "ON"
Interfaces	0 2 3 4 5		Legend ④	<without nameplate=""></without>	<optional marking="" plate=""></optional>	With nameplate "OFF"
Sensors	PLPLPBPBSS		Legends	<none></none>	<optional marking="" plate=""></optional>	With nameplate "HAND-AUTO"
AUTO-ID		Switch Part No.	Illuminated Voltage Contact Configuration	Part No. (Ordering Part No.)		
FB	<ul> <li>①Pilot Light (Round extended, red)</li> <li>②Pilot Light (Round extended, green)</li> <li>③Pushbutton (Momentary, flush, white)</li> <li>④Pushbutton (Momentary, extended, black)</li> <li>④Selector Switch (2-position maintained, knob, black)</li> </ul>	HW1P-2Q HW1P-2Q HW1B-M1 HW1B-M2 HW1S-2T	LED / 24V LED / 24V 1N01NC 1N01NC 1N01NC	FB3W-512Z-A05001	FB3W-512Z-A05002	FB3W-512Z-A05003

Symbol Specification	$\backslash$	Legend ①	<without nameplate=""></without>
Symbol Specification		Legend@	<without nameplate=""></without>
		Legend3	<without nameplate=""></without>
0 2 3 4 5		Legend@	<without nameplate=""></without>
(SS)PB)PB)PB)PB		Legends	<without nameplate=""></without>
	Switch Part No.	Contact Configuration	Part No. (Ordering Part No.)
<ul> <li>Selector Switch (2-position maintained, knob, black)</li> <li>Pushbutton (Momentary, flush, green)</li> <li>Pushbutton (Momentary, flush, green)</li> <li>Pushbutton (Momentary, flush, green)</li> <li>Pushbutton (Momentary, flush, green)</li> </ul>	HW1S-2T HW1B-M1 HW1B-M1 HW1B-M1 HW1B-M1	1N0 1N0 1N0 1N0 2N0	FB3W-512Z-A05004

## A Safety Precautions

- Turn off power before installation, removal, maintenance, and inspection. Failure to turn power off may cause electrical shocks or fire hazard.
- To avoid burning your hand, use the lamp holder tool when replacing the lamps.


For more information, visit http://eu.idec.com

## Instructions

## Installation

#### **Panel Mounting**

- 1. Installing the FB series from the front
- Using two M4 screws, install the base onto the panel. Recommended tightening torque: 1.4 to 2.0 N·m
- Determine the screw length in consideration of the base and panel thickness.
- . Mounting screws are not supplied with the FB series. Use M4 mounting screws.



#### 2. Installing the FB series from the rear

- . Insert four M4 tapped screws into holes for tapping screws on the back of the base (depth: 8 to 10 mm, tapping screw hole diameter: ø3.7 mm), and fasten the screws to a tightening torque of 1.3±0.1 N·m (Nitto Seiko M4-P-TITE).
- Mounting screws are not supplied with the FB series. Use M4 tapping screws (recommended screws: Nitto Seiko M4-P-TITE).
- The value of the recommended tightening torque has been confirmed with a M4 tapping screw (Nitto Seiko M4-P-TITE). When using other screws, check that the tapping screw hole is not damaged and the screw can be securely tightened.

#### 3. Installation using mounting bracket FB9Z-PK1

• Refer to installation instructions on C-020.

#### Installing and Removing the Switch/Pilot Light


· Refer to installation instructions for each unit.

#### Installing the Cable Gland

- · Break a desired knockout to mount a cable gland using a hammer and a screwdriver, and install the cable gland.
- . When breaking the knockout to make a cable gland hole, be careful not to damage the internal contact block.
- Note that cracks or burrs on the cable gland hole will degrade the waterproof characteristics.

#### Installing the Cover and Base

- Attach the cover to the base so that the TOP mark on the cover and base are in the same direction.
- Use cover mounting screws to attach the cover to the base. (Recommended tightening torque: 1.3±0.1 N·m)
- Make sure that the cover and the base are attached in the correct direction. Otherwise, the FB series may be damaged.




#### Installation using tapping screw hole inside the enclosure


- When using M3 tapping hole screws inside the enclosure, make sue to install the devices in consideration of the insulation distance and temperature rise. Damages caused by using devices other than those specified by IDEC are excluded from any warranty. Ensures installed with devices using tapping screw holes will not be UL or c-UL listed.
- M3 tapping screw hole (depth: 6 to 7mm, tapping screw hole diameter ø2.7m)
- Recommended tightening torque: 0.9 ±0.1 N·m, M3-P-TITE (Nitto Seiko)

## **Applicable Crimping Terminal HW/TW Series**


Non-insulated Terminal

Crimping terminal from A







IP20 terminal



#### Crrimping terminal from (B)




Dimensions for intallling insulated tube



See HW series catalog pages for applicable crimping terminals.

#### Wiring Directions



Control Boxes

## Pilot Lights

Emergency Stop Switches

Switches

Safety Products

Explosion Proof

Terminal Blocks

Relavs & Sockets

Circuit Protectors

Power Supplies

LED Illumination

Controllers

Operator Interfaces

Sensors

AUTO-ID

Switches &

Pilot Lights

Emergency Stop Switches

Enabling

Switches

Safety Products

Explosion Proof

Terminal Blocks

Relavs & Sockets

Power Supplies

LED Illumination

Circuit

Protectors


AUTO-ID

attached.

**Control Boxe** 

## Instructions

#### XW Series (Screw Terminal)



ø3.2mir 6.0max 3.0max


Insulated Terminal

\*1) When a spade terminal is used, the dimension is 4.7 to 5.9 mm.

- \* Be sure to install an insulating tube on the crimping terminal.
- \* When using crimping terminals for the XW series, use only one crimping terminal for each terminal.
- \* Make sure that the wiring does not contact the control stations.

#### Applicable Cable Gland

· Use cable glands with waterproof characteristics (IP65, TYPE 4X) which can be mounted on a panel thickness of 3 mm or more. \* Cable gland and Locking nuts are not



#### 1) When using flexible conduits (Example)

#### Flexible conduits: VF-03 (Made by Nippon Flex Co., Ltd.)

Controllers	Gland Port Size	Plastic Cable Gland	Metal Cable Gland
Operator	M20		RLC-103EC20 (Nippon Flex)
Interfaces	G1/2		RLC-103 (Nippon Flex)
Sensors	PG13.5		RBC-103PG13.5 (Nippon Flex)

#### When using multi-core cables (Example)

Gland Port Size	Plastic Cable Gland	Metal Cable Gland
M20	5311 1220 [Skintop-ST-M] Applicable gasket: GPM20 (LAPP, Germany)	ALS-DDEC20 (Nippon Flex)
G1/2	5380 6030 [Skintop-ST-PF] Applicable gasket: GP 050 (LAPP, Germany)	ALS16-ロロ (Nippon Flex)
PG13.5	5301 5030 [Skintop-ST] Applicable gasket: GP13.5 (LAPP, Germany)	ABS-ロロPG13.5 (Nippon Flex)

#### 3) Locking ring for cable gland (plastic, optional)

, , ,		
Gland Port Size	Locking Nut Part No. (made of plastic)	
M20	HW9Z-NM20 (IDEC)	
G1/2	HW9Z-G (IDEC)	
PG13.5	HW9Z-PG135 (IDEC)	

- The degree of protection of the cable gland examples described above is not NEMA TYPE 4X.
- . When using the FB series in North America, be sure to use UL approved plastic cable glands.
- Tighten cable glands to a torque of 3.0±0.3 N·m.
- \* Insufficient tightening of the cable gland may degrade the waterproof characteristics.
- \* Electric shock protection Class II is maintained only when a plastic cable gland is used.
- Determine the cable gland for a multi-core cable according to the outside diameter of the cable sheath.
- When wiring from the back of FB series, use the ø14 knockout on the back of the enclosure. A cable gland cannot be installed to the ø14 knockout.

## Notes

#### **Applicable Wire Size**

• Determine the wire size in consideration of the applicable wire for switches/pilot lights and the applicable diameter of cables.

#### Wiring

- · Avoid foreign objects such as dust, liquid, and oil from entering the switch while connecting a conduit or wiring.
- Do not twist or pull the cable of flexible conduit with excessive force. Otherwise, the wire, FB series, and switches/pilot lights may be damaged.
- Because the FB series is not provided with a PG terminal, bonding circuits cannot be interconnected.

#### Installation of switches/pilot lights on 30 mm centers

• When mounting HW/TW series control units on 30mm mounting centers (close mounting), make sure to use a barrier (optional: HW-VU1) to secure the insulation properties of the terminal. The barriers (HW-VU1) can be easily pressed into the side of the contact block.

#### Operation

- · Avoid any contact with oil or coolants. Otherwise, the FB series may be damaged.
- Use the FB series for INDOOR applications only.


## **Contact Cover Box**

#### Specifications, applicable units, and wiring

Same as the standard control stations.

#### Installing XW series to the FB1WR-111Z contact cover

- Remove the contact block and the locking ring from the operator and check that the rubber gasket is in place. Insert the operator from panel front into the panel hole. Attach the rubber gasket and the base to the operator unit (place the rubber gasket between the panel and the base) and tighten the locking ring using locking ring wrench MW9Z-T1. Recommended tightening torque: 2.0 N·m
- Attach the contact block to the operator. After wiring, attach the cover to the base using four cover mounting screws. Recommended tightening torque: 1.3±0.1 N·m
- Use a nameplate if necessary.
- Determine the panel thickness by excluding the thickness of the base (2.0 mm) and accessories (if used) from the maximum panel thickness for the switch/pilot light.



#### Notes

- Do not expose the cable to excessive force, otherwise failure or damage may be caused. When mounting strength is needed, insert M4 tapping screws from the front of the panel (screw tightening depth: 8 to 10 mm tapping screw hole: ø3.7 mm)
- Determine the mounting hole centers referring to the dimensions of the control stations.

#### APEM

Switches & Pilot Lights

Emergency Stop Switches Enabling Switches

Safety Products

```
Explosion Proof
```

```
Terminal Blocks
```

```
Relays & Sockets
```

```
Circuit
Protectors
```

Power Supplies

LED Illumination

Controllers

Operator Interfaces

Sensors

AUTO-ID

Instructions

## **Mounting Bracket**

**Hook Mounting** 

- Attach the FB9Z-PK1 mounting bracket on the FB series with the supplied screws (two M4 tapping screws).
- Recommended tightening torque: 1.3±0.1 N·m
- Do not tighten the FB9Z-PK1 onto the FB series with excessive force. The tapping screw hole may be damaged and may not securely hold the FB series.

## **Frame Mounting**

• The FB9Z-PK1 can be used as frame mounting brackets by attaching two FB9Z-PK1 as shown below.

FB Series

FB9Z-PK1

Two M4 Tapping Screws (supplied)


(Depth: 10mm)

Two M4 Tapping Screw Holes

Depth

10mm


Л



• Attach the FB9Z-PK1 on the FB series with the supplied screws (two M4 tapping screws).

Recommended tightening torque: 1.3±0.1 N·m.


- Do not tighten the FB9Z-PK1 onto the FB series with excessive force. The tapping screw hole may be damaged and may not securely hold the control station.
- Using two M6 screws, fasten the FB9Z-PK1 securely on the frame. Recommended tightening torque: 5.0±0.3 N·m



- M6 mounting screws and nuts are not supplied with the FB9Z-PK1.
- The value of the recommended tightening torque for M6 screws has been confirmed with a hexagon socket head screw. When other screws are used and tightened to a smaller torque, make sure that the screws do not become loose after mounting.

## Dimensions

All dimensions in mm.



Mounting Hole

Γ

59.5

10

12

1) Hook Mounting

FB Series		
FB1  (76mm)	FB2 (140mm)	FB3 (200mm)
76	140	200
93	156	216
114	177	237

FB3() (200mm)

200

18.5

12

## **Control Boxes**

APEM Switches & Pilot Lights Emergency Stop Switches Enabling Switches Safety Products Explosion Proof Terminal Blocks Relavs & Sockets Circuit Protectors Power Supplies LED Illumination Controllers Operator Interfaces Sensors AUTO-ID

DIN Rail Adapter

Instructions

## Mounting

## 1) Installing the FB9Z-PK3 DIN Rail Adapter

- To attach the FB9Z-PK3 on the FB series, position the positioning hole of the FB9Z-PK3 with the positioning boss in the enclosure using four M3 tapping screws (supplied) as shown in the figure below. Recommended tightening torque: 0.9±0.1 N·m
- Do not tighten the FB9Z-PK3 onto the FB series with excessive force. The tapping screw hole may be damaged and may not securely hold the control station.

## 2) Installing the DIN Rail

• To attach a DIN rail, use plain washers and spring washers on two M5 screws and tighten firmly.

Recommended tightening torque: 2.0  $\pm 0.1 \ \text{N·m}$ 

• DIN rail mounting screw (M5)

sions.

FB9Z-PK3.


M5 Screw Length Washer Thickness Washer Thickness

Spring V + Plain V

> DIN Rail Thickness

Ψm

Screw length: (spring washer thickness + plain washer thickness + DIN rail thickness) + 3 to 5 mm



• M5 screws, spring washers, and plain washers are not supplied.

• The length of DIN rail must be within the effective internal dimen-

The screw hole may be damaged and may not securely hold the

• Do not tighten the M5 screw onto the FB9Z-PK3 with excessive force.

FB Series

M5 Screw


DIN Rail

Spring Washer Plain Washer


- 3) Mounting Switches/Pilot Lights on DIN Rail
- Refer to each instruction sheet.

## 4) Installing the Separate Mounting Transformer

- After attaching the FB9Z-PK3 on the FB series, attach the separate mounting transformer on the FB9Z-PK3, using plain washers and spring washers on two M3 screws as shown in the figure below. Recommended tightening torque: 0.5 to 0.8 N·m
- Separate mounting transformer mounting screw (M3) Screw Length: (Spring washer thickness) + (Plain washer thickness) + 7 to 10 mm




- M3 screws, spring washers, and plain washers are not supplied.
- Do not tighten the screw with excessive force. The screw hole and the separate mounting transformer may be damaged.



#### FB9Z-PK3 Dimensions

All dimensions in mm.



For more information, visit http://eu.idec.com

# **Control Boxes**

## APEM

Switches & Pilot Lights

Emergency Stop Switches Enabling Switches

Safety Products

Explosion Proof

Terminal Blocks

Relays & Sockets

Circuit Protectors

Power Supplies

LED Illumination

Controllers

Operator Interfaces


Sensors

AUTO-ID

## Instructions



FB9Z-PK3 Installation Positions



Note: Only one DIN rail adapter can be used for FB1 (76mm).

#### 5) Other Precautions

- Rated current of terminal blocks depends on operating conditions such as wire type, number of bundle wires, and ambient temperature. Check the specifications of terminal blocks carefully, and use terminal blocks within the specification values. Otherwise electric shock or fire hazard may be caused.
- FB series is rated as Class II protection against electric shock (no reliance on installation protective measures, according to IEC 61140). When using a blank front enclosure as a junction box and grounding is necessary, provide appropriate grounding, for example installing a grounding terminal block inside the enclosure.
- . For wiring, refer to the instructions of the FB series and switches/pilot lights used.