SA1E



User-friendly, higih-performance photoelectric switches





Through-beam



Diffuse-reflective



Small-beam reflective



Polarized retro-reflective



Background suppression (BGS)




Coaxial polarized retro-reflective

Output reverse-polarity protection circuit


Several SA1E models are protected from incorrect wiring:

- Through-beam
- Polarized retro-reflective
- Diffuse-reflective
- Background Suppression (BGS)
- Small-beam Reflective




Long Distance Detection

Ideal for a wide range of application.




Various accessories




Background Suppression (BGS)

Detects objects of different colors

The improved sensing ability detects objects of different colors such as black and white more accurately.





Reflector

÷

センサ

Reflector Reflector

No blind zone!

=Þ

Reflector

Blind Zone

ノノー
センサ

Mail sorting

Sensors

Sensors

SA1E Miniature Photoelectric Switches (Built-in Amplifier)

ors							Oshla	0		Package Quantity: 1				
				Sensing Method	Sensing Range	Connection	Cable Length	Operation Mode	NPN Output	PNP Output				
			Т					Light ON	SA1E-TN1	SA1E-TP1				
						1m	Dark ON	SA1E-TN2	SA1E-TP2					
APEM			tmer				2m	Light ON	SA1E-TN1-2M	SA1E-TP1-2M				
Switches &	bear	Infrared LED	Vdjus			Cable		Dark ON	SA1E-TN2-2M	SA1E-TP2-2M				
Pilot Lights Control Boxes	-hgu	ared	vity A		20m			Light ON	SA1E-TN1-5M	SA1E-TP1-5M				
Emergency	Through-beam	Ē	w/Sensitivity Adjustment				5m	Dark ON	SA1E-TN2-5M	SA1E-TP2-5M				
Stop Switches			w/Se					Light ON	SA1E-TN1C	SA1E-TP1C				
Enabling Switches					See the characteristics on M-011.	M8 Connector	—	Dark ON	SA1E-TN2C	SA1E-TP2C				
Safety Products	\vdash	+	+					Light ON	SA1E-PN1	SA1E-PP1				
Explosion Proof	a		4		5.0m (50mm) When using IAC-R5/R8		1m	Dark ON	SA1E-PN2	SA1E-PP2				
	ectiv		tmen		3.0m (50mm)			Light ON	SA1E-PN1-2M	SA1E-PP1-2M				
Terminal Blocks	-refl		djust		When using IAC-R6	Cable	2m	Dark ON	SATE-PN2-2M	SATE-PP2-2M				
Relays & Sockets	Retro	Red LED	/ity A	Note: Maintain at least the distance shown in the	When using IAC-RS2			Light ON	SATE-PN1-5M	SATE-PP1-5M				
Circuit Protectors	Polarized Retro-reflective	۳	w/Sensitivity Adjustment	() between the SA1E	1.3m (150mm) When using IAC-RS1		5m	Dark ON	SATE-PN2-5M	SATE-PP2-5M				
Power Supplies	olari		w/Se	photoelectric switch and reflector. Reflectors are	1.6m (100mm)				SATE-PN2-5M	SATE-PP2-SM SA1E-PP1C				
_ED Illumination				not supplied and must be	When using IAC-R7 See the characteristics on M-012.	M8 Connector	—	Light ON	SATE-PNTC SATE-PN2C	SATE-PPTC				
	\vdash	+	-	ordered separately.	See the characteristics on M-012.			Dark ON						
Controllers							1m	Light ON	SA1E-DN2	SA1E-DP1				
Operator Interfaces	e		ment				2m -	Dark ON	SA1E-DN2 SA1E-DN1-2M	SA1E-DP2				
Sensors	ectiv	요	djust			Cable		Light ON	SATE-DNT-2M SA1E-DN2-2M	SA1E-DP1-2M				
AUTO-ID	Diffuse-reflective	nfrared LED	w/Sensitivity Adjustment		700 mm			Dark ON		SA1E-DP2-2M				
	ffuse	Infra	Sitiv				5m	Light ON	SA1E-DN1-5M	SA1E-DP1-5M				
			v/Ser					Dark ON	SA1E-DN2-5M	SA1E-DP2-5M				
			2		See the characteristics on M-012.	M8 Connector	—	Light ON	SA1E-DN1C	SA1E-DP1C				
SA1E	\vdash	+	-					Dark ON	SA1E-DN2C	SA1E-DP2C				
SA1E-L					20 to 200 mm Cable		1m	Light ON	SA1E-BN1	SA1E-BP1				
	Background Suppression		ig Range Adjustment					Dark ON	SA1E-BN2	SA1E-BP2				
	ppre		Adjus	_ اق		2m -	Light ON	SA1E-BN1-2M	SA1E-BP1-2M					
	Id Su	Red LED	ange		40 to 200 mm			Dark ON	SA1E-BN2-2M	SA1E-BP2-2M				
	Jroun	۳	sing F		Adjustable Sensing Range		5m	Light ON	SA1E-BN1-5M	SA1E-BP1-5M				
	Back		w/Sensin					Dark ON	SA1E-BN2-5M	SA1E-BP2-5M				
			>		See the characteristics on M-012.	M8 Connector	—	Light ON	SA1E-BN1C	SA1E-BP1C				
	$ \rightarrow$	+	-					Dark ON	SA1E-BN2C	SA1E-BP2C				
							1m	Light ON	SA1E-NN1	SA1E-NP1				
	tive		ment					Dark ON	SA1E-NN2 SA1E-NN1-2M	SA1E-NP2 SA1E-NP1-2M				
	Small-beam Reflective		djust			Cable	2m	Light ON Dark ON	SATE-NNT-2M SATE-NN2-2M					
	am	Red LED	ity A		50 to 150 mm				SATE-NN2-2M SA1E-NN1-5M	SA1E-NP2-2M				
	-ll-be	۳ ۲	nsitiv				5m	Light ON Dark ON	SATE-NNT-5M SA1E-NN2-5M	SA1E-NP1-5M SA1E-NP2-5M				
	Sma	1	w/Sensitivity Adjustment					Light ON	SATE-NN1C	SATE-NP2-SM SATE-NP1C				
			-				See the characteristics on M-012. M8 Connector —		See the characteristics on M.012 M8 Connector —		—	Dark ON	SATE-NNTC	SATE-NPTC
	\vdash	+	-											
	a		+				1	Light ON Dark ON	SA1E-XN1 SA1E-XN2	SA1E-XP1 SA1E-XP2				
	flectiv		tmen		2.0m (when using IAC-R9)	2.0m (when using IAC-R9)	2.0m (when using IAC-R9)			SATE-XNZ SATE-XN1-2M	SATE-XP2 SATE-XP1-2M			
	stro-re		Adjus		1.0m [100 mm]	Cable	2	Light ON Dark ON	SATE-XNT-2M SATE-XN2-2M	SATE-XPT-2M SATE-XP2-2M				
	zed Re	Red LED	Sensitivity Adjustment		(when using IAC-R10)				SATE-XNZ-ZM SATE-XN1-5M	SATE-XP2-2M SATE-XP1-5M				
	Polari	۳,	Sensi	Note: Reflector is not supplied	1.0m [100 mm] (when using IAC-R11)		5	Light ON Dark ON	SATE-XNT-5M SATE-XN2-5M	SATE-XPT-5M SATE-XP2-5M				
	Coaxial Polarized Retro-reflective		With S	and must be ordered separately.					SATE-XNZ-5M SATE-XN1C	SATE-XP2-5M SATE-XP1C				
					See the characteristics on M-013.	M8 Connector	—	Light ON Dark ON	SATE-XNTC SATE-XN2C	SATE-XPTC SATE-XP2C				
					000 IIIE GHALAGIGHSIIGS UH WI-UIS.			Dark UN	SATE-ANZU	SATE-AF20				

Specifications

Sensing Meth	nod	Through-beam	Polarized Retro-reflective	ensors
Part No.		SA1E-T	SA1E-P	
Power Voltage	je	12 to 24V DC (Operating range: 10 to 30V DC) equipped with	reverse-polarity protection	
Current Draw		Projector: 15 mA Receiver: 20 mA	30mA	
Sensing Rang	ge	20m	5.0m (IAC-R5/R8) 3.0m (IAC-R6) 2.0m (IAC-RS2) 1.3m (IAC-RS1) 1.6m (IAC-R7□) (Note 1)	APEM Switches & Pilot Lights
Adjustable Se	ensing Range			Control Boxes
Detectable Ob		Opaque	Opaque/mirror-like objects	
Hysteresis		• Produce		Emergency Stop Switches
Response Tim	ne	1 ms maximum		Enabling
Sensitivity Adj		Adjustable using a potentiometer (approx. 240°) Through-beam and polarized retro-reflective models are also	o available without sensitivity adjustment.	Switches Safety Products
Sensing Rang	ge Adjustment			
Light Source E	Element	Infrared LED	Red LED	Explosion Proof
Operation Mod	ode	Light ON/Dark ON	L.	Terminal Blocks
	/	NPN open collector or PNP open collector (30V DC, 100 mA n	maximum, short-circuit protection)	
Control Outpu	ut	Voltage drop: 2V max. (30V DC, 100 mA max) 1.2V max. (30V DC, 10 mA max)		Relays & Sockets Circuit Protectors
	/	1.2V max. (30V DC, 10 mA max) With output reverse connection protection control circuit		
LED Indicators	rs	Operation LED: Yellow Stable LED: Green		LED Illumination
t t ference l		Power LED: Green (Through-beam model projector)	The second is along provinity	Controllers
Interference P			Two units can be mounted in close proximity.	
Degree of Pro		IP67 (IEC 60529) Sublight: 10,000 k maximum, Incandescent Jame: 5,000 lux	· · · · · · · · · · · · · · · · · · ·	Operator Interfaces
	_ight Immunity	Sunlight: 10,000 lx maximum, Incandescent lamp: 5,000 lux	maximum (at receiver)	Sensors
Operating Ten		-25 to +55°C (no freezing) 35 to 85% RH (no condensation)		
Operating Hur Storage Temp		$-40 \text{ to } +70^{\circ}\text{C}$ (no freezing)		AUTO-ID
Insulation Res	· · · · · · · · · · · · · · · · · · ·	Between live part and mounting bracket: 20 MΩ maximum (5)	(5001/D0 moggar)	
Dielectric Stre		Between live part and mounting bracket: 20 MΩ maximum (5 Between live part and mounting bracket: 1000V AC, 50/60 Hz		———
Vibration Resi		Damage limits: 10 to 500 Hz, 90 m/s ² , 1 cycle 5 mins, in eacl		
Shock Resista		Damage limits: 1000 m/s ² , 6 shocks in each of 3 axes	11 01 5 4365	SA1E
OHOUR HUGHEL	Case	PC/PBT		SA1E-L
Material	Lens	РММА		<u> </u>
Withon a.	Indicator Model	PC		—
Weight	Cable Model	Projector: 30g , Receiver: 30g (Note 2)	30g (Note 2)	
(approx.)	Connector Model	Projector: 10g, Receiver: 10g	10g	
	00111.001		5	
Connection	Cable Model	ø3.5 mm, 2-core, 0.2 mm² cable	ø3.5 mm, 3-core, 0.2 mm ² cable	I

Note 1: Maintain at least the distance shown below between the SA1E photoelectric switch and reflector.

IAC-R5/R6/R8: 50 mm

IAC-R7: 100 mm

IAC-RS1/RS2: 150 mm

The detection distance cannot be guaranteed if the reflector is deformed or the tape type reflector is applied on uneven surface.

Note 2: Cable length: 1m (50g when the cable length is 2m. 110g when the cable length is 5m.)

Se

Specifications

	peomou							
nsors	Sensing Meth	od	Diffuse-reflective	Background Suppression (BGS)	Small-beam Reflective	Coaxial Polarized Retro-reflective (Transparent Object Sensing)		
	Part No.		SA1E-D 🗆	SA1E-B 🗆	SA1E-N 🗆	SA1E-X		
	Power Voltage	;	12 to 24V DC (Operating range:	2 to 24V DC (Operating range: 10 to 30V DC), equipped with reverse-polarity protection				
	Current Draw		30 mA			20 mA		
APEM	Sensing Rang	е	700 mm (using 200 × 200 mm white mat paper)	20 mm to preset (using 200 × 200 mm white mat paper)	50 to 150 mm (using 100 × 100 mm white mat paper)	2 m (using IAC-R9)		
Switches &	Adjustable Sensing Range		_	40 to 200 mm	-			
Pilot Lights Control Boxes	Detectable Ob	iject	Opaque/Transparent	Opaque	Opaque/Transparent	Opaque, transparent and mirror-like objects		
Emergency	Hysteresis		20% maximum	10% maximum	20% maximum	—		
	Response Tim	e	1 ms maximum			500 µs maximum		
Enabling Switches	Sensitivity Adj	ustment	Adjustable using a potentiometer (approx. 240°)	—	Adjustable using a potentiome	ter (approx. 240°)		
Safety Products	Sensing Rang	e Adjustment	_	6-turn control knob	-	_		
Explosion Proof	Light Source Element		Infrared LED	Red LED	L			
	Operation Mode		Light ON/Dark ON	L				
Terminal Blocks			NPN open collector or PNP oper	n collector (30V DC, 100 mA max	imum with short circuit protectio	n circuit)		
Relays & Sockets	Control Output		Voltage drop: 2V max. (30V DC, 100 mA)	Voltage drop: 2V max. (30V DC, 100 mA)	Voltage drop: 2V max. (30V DC, 100 mA)	Voltage drop: 2V max.		
Protectors			1.2V max. (30V DC, 100 mA) Output reverse-polarity protection circuit	Output reverse-polarity protection circuit	1.2V max. (30V DC, 100 mA) Output reverse-polarity protection circuit	(30V DC, 100mA)		
Power Supplies	LED Indicators		Operation LED: Yellow Stable LED: Green	Operation LED: Yellow	Operation LED: Yellow Stable LED: Green	Operation LED: Yellow		
	Interference P	revention	Two units can be mounted in cl	ose proximity.				
Controllers	Degree of Pro	tection	IP67 (IEC 60529)					
Operator Interfaces	Extraneous Lig	ght Immunity	Sunlight: 10,000 lux maximum, Incandescent lamp: 5,000 lux maximum (at receiver)					
	Operating Terr	nperature	-25 to +55°C (no freezing)	· ·	· ·			
Sensors	Operating Hur	nidity	35 to 85% RH (no condensation	ו)				
	Storage Temp		-40 to +70°C (no freezing)					
l	Insulation Res	istance	Between live part and mounting	g bracket: 20 MΩ maximum (500)	V DC megger)			
F	Dielectric Stre	ength		g bracket: 1000V AC, 50/60 Hz, 1				
SA1E	Vibration Resistance		Damage limits: 10 to 500 Hz 1 cycle 5 mins in each of 3 ayes		Damage limits: 10 to 55 Hz, double amplitude 1.5mm, 20 cycles in each of 3 axes			
	Shock Resistance		Damage limits: 1000 m/s², 6 sh	locks in each of 3 axes	Damage limits: 500 m/s ² , 10 s	hocks in each of 3 axes		
SA1E-L		Housing	PC/PBT		PBT	PC/PBT		
	Material	Lens	PMMA			4		
		Indicator cover	PC					
F	Weight	Cable Model	30g (Note 1)	35g (Note 2)	30g (Note 1)	35g (Note 2)		
	(approx.)	Connector Model	10g	25g	10g	20g		
	Connection	Cable Model	ø3.5 mm, 3-core, 0.2 mm² cab	0				
	Method	Connector Model	M8 connector (4-pin)					
L								

Note 1: Cable length: 1m (50g when the cable length is 2m. 110g when the cable length is 5m.) Note 2: Cable length: 1m (55g when the cable length is 2m. 120g when the cable length is 5m.)

Slit and Sensing Range


A slit, which changes the beam size of through-beam sensors, can easily be attached to the sensing side of the through-beam projector and receiver. Three different slit widths are available.

		w/Sensitivity Adjustment]
Slit		Sensing I	Range (m)	Minimum Detectable Object Width (mm) (Note 1		
		Attached on:				1
Part No.	Slit Width: A (See M-017)	Receiver	Receiver/Projector	Receiver	Receiver/Projector	
SA9Z-S06	0.5 mm	2.5	1.0	0.5	0.5	APEM
SA9Z-S07	1.0 mm	3.5	1.5	1.0	1.0	Switches &
SA9Z-S08	2.0 mm	6.0	3.5	2.0	2.0	Pilot Lights
SA9Z-S09	0.5 mm	2.0	0.7	0.5	0.5	Control Boxes
SA9Z-S10	1.0 mm	3.0	1.5	1.0	1.0	Emergency
SA9Z-S11	2.0 mm	5.5	3.0	2.0	2.0	Stop Switches
SA9Z-S12	0.5 mm	0.8	0.08	0.5	0.5	Enabling Switches
SA9Z-S13	1.0 mm	1.5	0.3	1.0	1.0	Safety Products
SA9Z-S14	2.0 mm	2.5	1.2	2.0	2.0	

Note 1: At 1mm from receiver surface.

• The slit can be installed onto the front easily (see the figure at right).

The slit can be pressed to snap onto the front easily.




Horizontal slits and round slits have an orientation. Make sure that the TOP marking comes on top of the sensor (LED side).


Output Circuit & Wiring Diagram

Through-beam Polarized reflective Diffuse-reflective Background suppression (BGS) Small-beam reflective


NPN Output



PNP Output




Brown (1)




Coaxial polarized retro-reflective (Transparent Object Sensing)

NPN Output




Connecto	or Pin As	signment
① (OUT)	60	3 (OV)
2 (NC)	les/	@ (+V)


PNP Output



Through-beam Projector



Through-beam Projector



Explosion Proof

Terminal Blocks Relays & Sockets

Circuit

Protectors


AUTO-ID

SA1E-L

Power Supplies LED Illumination Controllers Operator Interfaces

Cable Model Through-beam APEM Switches & Pilot Lights Control Boxes Emergency Stop Switches Enabling Switches Safety Products Polarized retro-reflective Explosion Proof **Diffuse-reflective** Terminal Blocks **Background Suppression (BGS)** Relays & Sockets Small-beam reflective

Dimensions



*1: Stable LED is not installed on background suppression (BGS) model.

All dimensions in mm

11.7

Coaxial polarized retro-reflective (Transparent Object Sensing)

SA1E SA1E-L


AUTO-ID


Circuit Protectors

Power Supplies

LED Illumination Controllers Operator Interfaces








bownload catalogs and CAD from http://eu.idec.com/downloads

Coaxial polarized retro-reflective (Transparent Object Sensing)






*2: The connector length is 18 mm when a right-angle connector cable (SA9Z-CM8K-4L□) is attached.

Interfaces

AUTO-ID

Characteristics (Typical)



Sensors

APEM

IAC-R5

6 7 8

Switches & Pilot Lights

Control Boxes

Emergency

Stop Switches Enabling

Switches

Safety Products

Explosion Proof

Terminal Blocks

Relays & Sockets

Circuit

Protectors

Power Supplies

LED Illumination


Controllers

Operator Interfaces

nsors

AUTO-ID

SA1E SA1E-L




IAC

Excess Gain

Operation

Level


10




Angle (when using IAC-R5/-R8) 80 IAC-BS1 60 IAC-RS 40 Reflector Angle 0 (°) 20 IA(0 -20 -40 -60 -80 4 5 0 2 3 Sensing Distance X (m)

3. Diffuse-Reflective SA1E-D□

Sensing Distance (m)




5. Small-beam Reflective SA1E-N□



Download catalogs and CAD from http://eu.idec.com/downloads

6. Coaxial Polarized Retro-reflective SA1E-X



LED Illumination

Sensors

Controllers Operator Interfaces

AUTO-ID

SA1E
SA1E-L

APEM Switches & Pilot Lights Control Boxes

Emergency

Stop Switches Enabling Switches Safety Products

Explosion Proof Terminal Blocks Relays & Sockets

LED Illumination

Controllers

Operator

Interfaces

AUTO-ID

Circuit

Accessories (optional)

Slits (for through-beam)

Item	Slit Size	Part No.	Ordering No.	Package Quantity
	$0.5 \text{ mm} \times 18 \text{ mm}$	SA9Z-S06	SA9Z-S06PN02	
Vertical Slit	1.0 mm × 18 mm	SA9Z-S07	SA9Z-S07PN02	
	2.0 mm × 18 mm	SA9Z-S08	SA9Z-S08PN02	
	$0.5 \text{ mm} \times 6.5 \text{ mm}$	SA9Z-S09	SA9Z-S09PN02	
Horizontal Slit	1.0 mm × 6.5 mm	SA9Z-S10	SA9Z-S10PN02	2
	$2.0 \text{ mm} \times 6.5 \text{ mm}$	SA9Z-S11	SA9Z-S11PN02	
	ø0.5 mm	SA9Z-S12	SA9Z-S12PN02	
Round Slit	ø1.0 mm	SA9Z-S13	SA9Z-S13PN02	
	ø2.0 mm	SA9Z-S14	SA9Z-S14PN02	

Reflectors (for polarized retro-reflective)

	Item	Part No.	Package Quantity
	Standard	IAC-R5	
	Small	IAC-R6	
	Large	IAC-R8	
Reflector	Narrow (rear/side mounting)	IAC-R7M	
Reflector	Narrow (rear mounting)	IAC-R7B	
	Narrow (side mounting)	IAC-R7S	1
	Tape Type (40 \times 35 mm)	IAC-RS1	
	Tape Type (80 \times 70 mm)	IAC-RS2	
Reflector	For IAC-R5	IAC-L2	
Mounting	For IAC-R6	IAC-L3	
Bracket	For IAC-R8	IAC-L5	

See M-016 to M-017 for dimensions.

- The IAC-L2 is not supplied with mounting screws and nuts. Use commercially available M4 screws and nuts for mounting the IAC-R5 reflector.
- The IAC-L3 is supplied with two mounting screws (M3 × 8 mm sems screws).
- The IAC-L5 is supplied with two mounting screws (M4 × 10 mm sems screws).
- The IAC-R7M and IAC-R7S are supplied with two M3 × 8 mm self-tapping screws, two flat washers, and two spring washers.
- The IAC-R7B is supplied with an M3 × 8 mm self-tapping screw, a flat washer, and a spring washer.

Sensor Mounting Brackets

	Item	Part No.	Package Quantity
	Vertical Mounting	SA9Z-K01	
Main Unit	Horizontal Mounting	SA9Z-K02	1
Mounting Brackets	Cover type	SA9Z-K03	
	Back Mounting	SA9Z-K04	1

• Two mounting screws (M3 × 12 mm sems screws) are supplied with the SA9Z-K01 and SA9Z-K02.

• Two mounting screws (M3 × 14 mm sems screws) are supplied with the SA9Z-K03.

• The through-beam model requires two mounting brackets, one each for the projector and the receiver.

- The SA9Z-K02 cannot be used for the connector models.
- Contact IDEC about mounting brackets for the connector.

Connector Cable (for M8 connector model)

Number of Core Wires	Style & Length	Part No.	Package Quantity
	Straight, 2m	SA9Z-CM8K-4S2	
	Right angle, 2m	SA9Z-CM8K-4L2	-
4	Straight, 5m	SA9Z-CM8K-4S5	1
	Right angle, 5m	SA9Z-CM8K-4L5	

Reflectors

(used only for coaxial polarized retro-reflective)

Item		Part No.	Package Quantity
	Standard	IAC-R9	
Reflector	Small	IAC-R10	1
	Ultra-small	IAC-R11	
Reflector Mounting Bracket	For IAC-R9	IAC-L3	

Air Blower Mounting Block

j=						
like we	Devit Ma	Dealer of Ourselite	Protectors			
Item	Part No.	Package Quantity	Derror Ormelie e			
Air Blower Mounting Block	SA9Z-A02	1	Power Supplies			

 Two mounting screws (M3 × 20 mm sems screws), one M5 × 6 mm screw for plugging the air supply port, and one gasket (0.5 mm thick) are supplied.


• The air tube fitting and mounting bracket are not supplied and must be ordered separately (recommended mounting bracket: SA9Z-K01).

• Material: Anodized aluminum surface


Sensitivity Control Screwdriver

Item	Part No.	Package Quantity
Sensitivity Control Screwdriver	SA9Z-AD01	1


SA1E-L




Back Mounting SA9Z-K04




With Mounting Bracket







For more information, visit http://eu.idec.com



(Reflecting surface 18×18.2)





(Reflecting surface 38.5×16)


bownload catalogs and CAD from http://eu.idec.com/downloads

Accessory Dimensions All dimensions in mm **Reflector Mounting Brackets** IAC-L2 (for IAC-R5) IAC-L3 (for IAC-R6) IAC-L5 (for IAC-R8) 42 σ 28 APEM Switches & 6 5.5 Pilot Lights 30 Control Boxes `\$ Emergency Stop Switches \oplus 4-ø4.4 Enabling ₿ Switches \oplus 3 2-ø3.4 Safety Products 60 74 37 50 Explosion Proof 35 113 40 25 Terminal Blocks \oplus \oplus ф 9 Ф \oplus Ф Relays & Sockets 22 9 12 35 61 Circuit Ф Φ \oplus ⊕ 4 9 Protectors φ ф α ∞ Power Supplies \oplus ¢ 42 ¢ 9 \sim 8-M3 × 0.5 holes 3 26 20 LED Illumination 58 20 (28) $8-M3 \times 0.7$ holes Material: SPCC (zinc chromate plating, black) Material: SPCC (zinc plating) Controllers Material: SPCC (zinc plating) Operator Interfaces Connector Cable (connector on one end) AUTO-ID Vertical Slit Horizontal Slit **Round Slit** Straight **Right-angle** SA9Z-S06 SA9Z-S12 (SA9Z-CM8K-4S□) (SA9Z-CM8K-4L□) SA9Z-S09 SA9Z-S07 SA9Z-S10 SA9Z-S13 18.9 SA9Z-S08 SA9Z-S11 SA9Z-S14 ④ Black 2 White Black 2 White D Ø10 O 3 Blue 1 Brown 3 Blue 1 Brown SA1E-L 8 27. 33. ø4.7 Ř

• Dielectric strength when installed on the SA1E: 1000V AC (between live part and mounting bracket, except between live part and tightening ring)



Cable length: 2 or 5m




- The SA9Z-A02 air blower mounting block is supplied with two mounting screws (M3 \times 20 mm sems screws), one screw for plugging the air supply port (M5 \times 6 mm), and one gasket for plugging the air supply port.
- An air tube fitting (M5) can be installed to either the top or side. Tighten the fitting to a torque of 0.5 N·m maximum.
- The air tube fitting and mounting bracket are not supplied and must be ordered separately (recommended mounting bracket: SA9Z-K01).

5

Cable length: 2 or 5m Ш ø4.7 32.1 ∞ Ś Material: Stainless Steel Note: For slit width A, see M-008.

Indicator and Output Operation (except for background suppression model)

• The operation LED turns on (yellow) when the control output is on.



- The stable LED turns on (green) either at stable incident or stable interruption. Make sure to use the photoelectric switch after the stable operation is ensured.
- In the light ON operation, the output turns on when the receiving light intensity level is 1.0 or over as shown on the right.
- In the dark-ON operation, the output turns on when the receiving light intensity level is 1.0 or less as shown on the right.

Receiving Light Intensity Level		Light Receiving Status	Stable LED (green)	Operation LED (yellow)/ Control Output	
				Light ON	Dark ON
	1.2 and over	Stable Incident	ON	ON OFF	OFF
Operation Level	1.0	Unstable Incident	OFF		UFF
		Unstable Interruption		OFF	ON
	0.8 and below	Stable Interruption	ON		

Optical Axis Alignment (Light ON)

Through-beam

Fasten the receiver temporarily. Place the projector to face the receiver. Move the projector up, down, right and left to find the range where the operation LED turns on. Fasten the projector in the middle of the range. Next, move the receiver up, down, right and left in the same manner and fasten in the middle of the range where the operation LED turns on. Make sure that stable LED turns on at stable incident and stable interruption.

Polarized retro-reflective

Install the reflector perpendicularly to the optical axis. Move the SA1E photoelectric switch up, down, right and left to find the range where the operation LED turns on. Fasten the switch in the middle of the range. Polarized retro-reflective model can be installed also by finding the position where the reflection of projected red light is most intense, while observing the reflection on the reflector from behind the switch. Make sure that stable LED turns on at stable incident and stable interruption.

Diffuse-reflective/Small-beam reflective

Place the SA1E photoelectric switch where the switch can detect the object. Move the switch up, down, right and left to find the range where the operation LED tuns on. Fasten the switch in the middle of the range. Make sure that stable LED turns on at stable incident and stable interruption. Because the light source element of small-beam reflective model is a red LED, visual inspection is possible as well.

Sensitivity Adjustment

Referring to the table at right, adjust the sensitivity of the SA1E photoelectric switch when necessary, in such cases as the throughbeam model is used to detect small or translucent objects or the reflective model is affected by background. The table explains the status of operation LED when the operation mode is set to light ON.

• After adjusting the sensitivity, make sure that stable LED turns on at stable incident and stable interruption. For detecting objects too small to turn on the stable LED, use an optional slit.

 Sensitivity is set to the maximum (+) at the factory before shipment. When adjusting the sensitivity, use the screwdriver supplied with the SA1E photoelectric switch to turn the control as shown below, to a torgue of 0.05 N·m maximum.

Step	Photoelectric Switch Status	Sensitivity Control	Adjusting Procedure	
1	Receiving light • Through-beam, polarized reflective: No object detected • Diffuse reflective, small-		Turn the control counter-clockwise to the minimum (–). Then turn clock- wise (toward +) until the operation LED turns on (turns off with dark ON type) (point A).	APEM Switches & Pilot Lights Control Boxes
	beam reflective: Object detected	> 1		Emergency Stop Switches
	Light is interrupted		At interruption status, turn the	Enabling Switches
Through-beam, polarized reflective: Object detected		control clockwise (toward +) from point A, until the operation LED turns	Safety Products	
	Diffuse reflective, small-		on (turns off with dark ON type) (point B).	Explosion Proof
2 beam reflective: No object detected		If the operation LED does not turn on (turn off with dark ON type) even	Terminal Blocks	
		BK	though the control has reached the maximum (+), set the maximum	Relays & Sockets
			position (+) as point B.	Circuit Protectors
			Set the middle point between point A and B as point C.	Power Supplies
3 —			LED Illumination	
		BL		Controllers


Adjustment of Sensing Range for Background Suppression (BGS) Model

When adjusting the sensing range, follow the instruction below.

Step	Distance Control	Adjusting Procedure
1		Install the photoelectric switch and the object firmly. Turn the control counterclockwise until the operation LED turns off (turns on with dark ON type). From this point, turn the control clockwise until the operation LED turns on (turns off with dark ON type) (point A).
2	A B	Remove the object, and confirm that the operation LED turns off (turns on with dark ON type). Turn the control clockwise until the operation LED turns on (detecting the background) (turns off with dark ON type) (point B). (Note 1)
3	C B	Set the middle point between point A and B as point C. (Note 2)

- Note 1: When the background is far off and not detected, turn the control 360°, and set the point as point C.
- Note 2: Because the control is multi-turn, it may take more than one turn to move from point A to point B.
- Note 3: Turning the control clockwise lengthens the sensing distance.
- Note 4: Background suppression (BGS) model is not provided with a stable LED.

Operation LED (yellow)



AUTO-ID

Operating Instructions

Power Supply and Wiring

- Do not use the SA1E photoelectric switch at the transient status immediately after turning on the power (approx. 100 ms, background suppression model: 200 ms). When the load and switch use different power supplies, make sure to power up the switch first.
- Use a power supply with little noise and inrush current, and use the APEM photoelectric switch within the rated voltage range. Make sure that ripple factor is within the allowable limit. Do not apply AC voltage, otherwise the switch may blow out or burn.
 - . When using a switching power supply, make sure to ground the FG (frame ground) terminal, otherwise high-frequency noise may affect the photoelectric switch.
 - Turn power off before inserting/removing the connector on photoelectric switch. Make sure that excessive mechanical force is not applied to the connector. Connect the connector cable to a tightening torque of 0.5 N·m maximum.
 - To ensure the degree of protection, use the applicable connector cable for the connector model. Connector cables are ordered separately.
 - Avoid parallel wiring with high-voltage or power lines in the same conduit, otherwise noise may cause malfunction and damage. When wiring is long, use a separate conduit for wiring.
 - Use a cable of 0.3 mm² minimum core wires, then the cable can be extended up to 100m.

Installation

Installing the Photoelectric Switch

- . Do not install the SA1E photoelectric switches in an area where the switches are subject to the following conditions, otherwise malfunction and damage may be caused.
- * Inductive devices or heat source
- * Extreme vibration or shock
- * Large amount of dust
- * Water, oil, chemicals
- * Outdoor
- Make sure to prevent sunlight, fluorescent light, and especially the fluorescent light of inverters from entering the receiver of the photoelectric switch directly. Keep the through-beam model receiver away from intense extraneous light.
- Interference prevention allows two SA1E switches to be mounted in close proximity. However, the through-beam model is not equipped with interference prevention. Maintain appropriate distance between the switches referring to the lateral displacement characteristics.
- Because the SA1E photoelectric switches are IP67 waterproof, the SA1E can be exposed to water. However, wipe water drops and smears from the lens and slit using a soft cloth to make sure of the best detecting performance.
- Polycarbonate or acrylic resins are used for optical elements. Do not use ammonia or caustic soda for cleaning, otherwise optical elements will be dissolved. To remove dust and moisture build-up, use soft dry cloth.
- Tighten the mounting screws (M3) to a torque of 0.5 N·m. Do not tighten the mounting screws excessively or hit the switch with a hammer, otherwise the protection degree cannot be maintained.

Installing the Reflector


- Use M4 mounting screws for the IAC-R5 and IAC-R8 reflector, and M3 mounting screws for the IAC-R6 reflector. Tighten the mounting screws to a tightening torgue of 0.5 N·m maximum. Mounting screws are not supplied with the switch.
- Use the M3 self-tapping screw, flat washer, and spring washer to tighten the IAC-R7 reflector to a torque of 0.5 to 0.6 N·m.
- Optional reflector mounting bracket IAC-L2 is not supplied with mounting screws or nuts.
- IAC-L3 and IAC-L5 are supplied with mounting screws for mounting the reflector on the bracket.
- Reflector IAC-RS1 and IAC-RS2 can be installed directly on a flat surface using the adhesive tape attached to the back of the reflector. Before attaching the reflector, clean the board surface to ensure secure attachment.

Installing the air blower mounting block SA9Z-A02

- When installing the SA9Z-A02 on the SA1E photoelectric switch, use the attached M3 \times 20 mounting screws and tighten to a torque of 0.5 N·m maximum.
- Do not use the mounting screw (M3 \times 12) supplied with the mounting bracket (SA9Z-K01) to mount the SA1E photoelectric switches.
- The SA9Z-A02 cannot be used with the through-beam slits (SA9Z-S06 to S14).
- The air tube fitting (M5) can be installed to either the top or side. The air tube is not supplied.
- · Close the unused port using the air supply port plugging screw and gasket (supplied with SA1E) to a tightening torque of 1 to 2 N·m maximum. The recommended air pressure is 0.1 to 0.3 MPa.

Installing the background suppression (BGS) model

 This sensor can detect objects correctly when the sensor head is installed perpendicular to the moving object. Install the sensor head as shown below to minimize sensing errors.



• If the sensor is used in a place subject to a large variations in the ambient temperature, the characteristics may change depending on the target object. Be sure to check the operation under the actual operating conditions.

Sensors

Switches & Pilot Lights

Control Boxes

Emergency Stop Switches

Enabling

Switches

Safety Products

Explosion Proof

Terminal Blocks

Relavs & Sockets

Power Supplies

LED Illumination

Controllers

Operator

Interfaces

AUTO-ID

SA1E-L

Circuit

Protectors